



Place R5 => MPU-9250
No Place R5 => MPU-6500

Zero Ohm Jumpers:
 R2 = nCS I2C=VDD SPI = Remove R2
 R4 = AD0/SDO LSB of I2C Address SPI = Remove R4
 R6 = FSYNC If not used connect to GND

Title **EMSENSR-9250,6500-BOB**

Embedded Masters LLC

Size: A4 Number: Revision: 1.0

www.embeddedmasters.com

Date: 3/5/2014 Time: 11:37:20 AM Sheet 1 of 1

File: EMSENSR-9250,6500-BOB.SchDoc

