BLE113 DEVELOPMENT KIT

QUICK START

Thursday, 14 March 2013

Version 1.5



Copyright © 2000-2013 Bluegiga Technologies

Bluegiga Technologies reserves the right to alter the hardware, software, and/or specifications detailed herein at any time without notice, and does not make any commitment to update the information contained herein. Bluegiga Technologies assumes no responsibility for any errors which may appear in this manual. Bluegiga Technologies' products are not authorized for use as critical components in life support devices or systems.

Bluegiga Access Server, Access Point, APx4, AX4, BSM, iWRAP, BGScript and WRAP THOR are trademarks of Bluegiga Technologies.

The Bluetooth trademark and logo are registered trademarks and are owned by the Bluetooth SIG, Inc.

ARM and ARM9 are trademarks of ARM Ltd.

Linux is a trademark of Linus Torvalds.

All other trademarks listed herein belong to their respective owners.

TABLE OF CONTENTS

1	Intro	pduction	4	
2	Wha	at is BLE113 Bluetooth Smart Module	4	
	2.1	Key features	4	
3	BLE	113 Development Kit contents	5	
4	Getti	ting started with BLE113	6	
	4.1	Development overview	6	
	4.2	Preparations	7	
	4.3	Using the DKBLE113 for the first time	7	
5	Blue	egiga Bluetooth Smart Tools	9	
6	Blue	Bluetooth Smart Documentation		
7	Cont	Contact Information		

1 Introduction

This document is a getting started guide for the Bluegiga BLE113 development kit. The guide instructs you how to set up the BLE113 development kit, power it up and access the BLE113 using the BLEGUI software.

2 What is BLE113 Bluetooth Smart Module

BLE113 is a *Bluetooth* smart module targeted for small and low power sensors and accessories. It integrates all features required for a *Bluetooth* smart application: *Bluetooth* radio, software stack and GATT based profiles. BLE113 *Bluetooth* smart module can also host end user applications, which means no external micro controller is required in size or price constrained devices. BLE113 *Bluetooth* smart module also has flexible hardware interfaces to connect to different peripherals and sensors. BLE113 *Bluetooth* smart module can be powered directly from a standard 3V coin cell battery or pair of AAA batteries. In lowest power sleep mode it consumes only 500nA and will wake up in few hundred microseconds.

2.1 Key features

- *Bluetooth* v.4.0, single mode compliant
 - Supports master and slave modes
 - Up to 8 simultanous connections
- Integrated *Bluetooth* Smart stack
 - GAP, GATT, L2CAP and SMP
 - Bluetooth Smart profiles
- Radio performance
 - Transmit power : +0 dBm to -23 dBm
 - Receiver sensitivity: up to -93 dBm
- Ultra low current consumption
 - Transmit: 18.2 mA (0 dBm)
 - Transmit: 14.3 mA (0 dBm with DC/DC)
 - Receive: 14.3 mA
 - Sleep mode 3: 0.4uA
- Flexible peripheral interfaces
 - UART or SPI
 - I2C
 - PWM, GPIO
 - 12-bit ADC
- Host interfaces
 - UART
- Programmable 8051 processor for stand-alone operation
 - Simple Bluegiga BGScriptTM scripting language for quick application development
 - Bluegiga Profile ToolkitTM allowing the quick development of GATT based profiles
 - Free Software Development Kit
- Bluetooth, CE, FCC, IC, Japan and South-Korea qualified

Bluegiga Technologies Oy

3 **BLE113 Development Kit contents**

The BLE113 development kit is a ready-to-use hardware development platform for the Bluegiga BLE113 *Bluetooth* Smart module. The development kit consists of a single BLE113 development board, programming cables, two BLE113 modules and a BLED112 USB dongle.

DKBLE113 development kit contents

- 1 x Bluegiga BLE113 development board containing
 - BLE113 Bluetooth Smart module
 - o Display
 - Accelerometer (Freescale MMA8451QT)
 - Altimeter (Freescale MPL3115A2)
 - Potentiometer
 - USB to UART bridge and micro USB connector
 - o CR2032 battery holder
 - o DC/DC converter (Texas Instruments TPS62730)
 - o Debug interface
 - o IO headers
- 2 x BLE113 *Bluetooth* Smart modules
- 1 x BLED112 USB dongle
- 1 x USB cable
- 1 x CR2032 battery
- 1 x Firmware programming cable (CC Debugger)
- Documentation



Figure 1: BLE113 development board

4 Getting started with BLE113

4.1 Development overview



Figure 2: Development path

Bluegiga Technologies Oy

4.2 Preparations

- 1. Log in to Bluegiga Tech Forum at: <u>http://techforum.bluegiga.com</u>
 - a. If you do not have an account yet, you can create one at http://techforum.bluegiga.com/create_account
- 2. Download all BLE113 documentation, *Bluetooth* Smart SDK and software tools

4.3 Using the DKBLE113 for the first time

Step 1: Power on the BLE113 development board

If powering the BLE113 development board via USB:

- 1. Make sure the display switch on the BLE113 development board is turned **ON**
- 2. Check the **USB CURR MEAS** jumper is in place.
- 3. Make sure the power switch is in **USB** position
- 4. Connect the BLE113 development board using the supplied micro USB cable to a PC
- 5. Check that he green power led turns on

If powering the BLE113 development board with a **CR2032** battery:

- 1. Make sure the display switch on the BLE113 development board is turned ON
- 2. Make sure the USB to UART converter switch is turned OFF
- 3. Check the **BATTERY CURR MEAS** jumper is in place.
- 4. Make sure the power switch is in **BAT** position

Note:

If the factory default configuration the BLE113 development kit has a pre-programmed firmware that will start *Bluetooth* low energy advertisement and display information on the display. Also the UART interface is disabled by default.

Note:

If CR2032 battery is connected to the BLE113 development board and the power switch is turned to the **USB** mode a led will turn on, which will slowly drain the CR2032. It's recommended the CR2032 is fully removed or the **BATTERY CURR MEAS** jumper disconnected.

Step 2: Connect BLED112 USB dongle to a PC and install driver

- 1. Connect the BLED112 USB dongle to a Windows PC.
- 2. Windows will recognize the BLED112 USB dongle and prompt for a driver.
- 3. The USB driver is in the *Bluetooth* Smart SDK's *windrv* folder.
- 4. Once the driver has been installed, the BLED112 USB dongle should appear as a virtual COM port in Windows device manager.

Step 3: Start BLEGUI software and discover the BLE113 development kit

- 1 When the BLE113 development board is powered the display will show the following text: **"DKBLE113" "Temp. : <temperature in Celsius>**₀**C**
- 2 The sample firmware also starts *Bluetooth* low energy advertisements.
- 3 To discover the BLE113 development board, start the **BLEGUI application** included in the *bin* folder of the *Bluetooth* Smart SDK.
- 4 In BLEGUI application, select the Bluegiga *Bluetooth* Low Energy COM port and press Attach. Make sure the status changes to Connected.
- 5 Start **Generic scan** operation and you start to receive Advertisement packets in the **BLEGUI** application.
- 6 Read *Health Thermometer Profile application* note to learn more about the demo.

I MainWindow					
Tools Commands					
GAP					
Mode	Refresh Bluegiga Bluetooth Low Energy (COM28)				
Discoverable Generic 🔻	Public: 00:07:80:ff:ff:f2				
Connectable Undirected	DKBLE112 thermometer RSSI: 40 (62%) Update Connect Encrypt GATT				
Set Mode	General No_BREDR Connectable undirected Scan Rsp				
Clear Mode					
Adv Interval 1280.00 ms 2048					
Set Adv Parameters					
- Scan					
© Limited					
 Generic 					
Observation					
Start					
Stop					
Scan Interval 10.00 ms 16 🚔					
Set Scan Parameters					
	Interval 40 束 75.00 ms Timeout 100 束 1000ms Update Refresh Clear				
Log					
data:02010615094440524c4531313220746865726d6f6d65746572 2011.11.09 22:28:03.0890 RX: 802306002800f2fff80070000190201061509444b424c4531313220746865726d6f6d65746572 2011.11.09 22:28:03.0890 RX: 8023060028000280002800028000000000000000					
2011.11.09 22:28:04.0098 RX: 800a06002804f2ffff8007000000					
	Clear				

Figure 3: Discovering DKBLE113

5 Bluegiga Bluetooth Smart Tools

- **BLEGUI:** This application can be used to control BLE112, BLE113 or BLED112 over UART or USB. BLEGUI is a terminal like program that sends the BGAPI command to the *Bluetooth* Smart module and parses the responses. It's a useful tool to get familiar with the products and try out *Bluetooth* low energy applications.
- **BLE Update:** This tool can be used to compile and install *Bluetooth* Smart SDK projects into Bluegiga *Bluetooth* Smart products using the CC debugger programming cable.
- **iOS reference application:** The iOS reference application implements the Heart Rate Collector and Cable Replacement (CR) collector profiles for Apple's Bluetooth 4.0 compatible iOS devices and is available as a source code.
- **BGBuild:** BGBuild application compiles the hardware configuration file, GATT database, BGScript and the *Bluetooth* Smart stack into a single binary image (.hex), which can be installed into BLE112, BLE113 or BLED112 hardware.
- **DFUTool:** DFUTool can be used to update the firmware of BLE112, BLE113 or BLED112 using USB DFU protocol.
- **Thermometer-demo:** Thermometer demo is a Windows command line application, which implements Thermometer collector using BGLib. It can scan *Bluetooth* 4.0 single-mode devices, and read temperature values from them.
- **Collector demo:** Collector demo implements a simple Windows HR collector application, which scans, connects and reads HR and Battery status values from a HR sensor

6 Bluetooth Smart Documentation

- **Bluetooth low energy getting started**: This document, describes the very basics of *Bluetooth* Smart technology and related Bluegiga *Bluetooth* Smart products
- **BGScript developer guide:** Describes the BGScript scripting language, its features and limitations. Contains also a lot of practical BGScript examples.
- **Profile developer toolkit developer guide:** Describes the basics of *Bluetooth* Smart profile development, as well the features and syntax of hardware and GATT XML files. Contains also practical examples.
- **Bluetooth Smart stack API reference:** This document contains the BGAPI, BGLib and BGScript API. Describes the available commands, responses, events and their parameters. API reference document also explains the basics of *Bluetooth* low energy technology.
- BLEGUI User Guide: The document describes how the BLEGUI application works and how to use it
- **Application notes:** Various application notes describe specific use cases like for example Heart Rate Sensor or Health Thermometer collector and walk through the necessary development steps required to implement those.

7 Contact Information

Sales:	sales@bluegiga.com
Technical support:	support@bluegiga.com
	http://techforum.bluegiga.com
Orders:	orders@bluegiga.com
www:	www.bluegiga.com
	www.bluegiga.hk
Head Office / Finland:	
	Phone: +358-9-4355 060
	Fax: +358-9-4355 0660
	Sinikalliontie 5A
	02630 ESPOO
	FINLAND
Postal address / Finland:	
	P.O. BOX 120
	02631 ESPOO
	FINLAND
Salas Office / USA:	
Sales Office / USA:	Dhono: 11 770 201 2121
	Fille: +1 770 201 2101
	Fax. +17702912103
	2225 Satellite Boulevard, Building 400, Suite 200
	Duluth CA 30006 LISA
	Duluiti, CA, 50030, COA
Sales Office / Hong-Kong:	
	Phone: +852 3972 2186
	Bluegiga Technologies Ltd.
	Unit 10-18
	32/F, Tower 1, Millennium City 1
	388 Kwun Tong Road
	Kwun Tong, Kowloon
	Hong Kong